




# 1293 PE distribution x=1500mm y=75mm




Example of a 96PE pulse




Example of a 103PE pulse




Example of a 260PE pulse




Example of a 269PE pulse




1293 PE distribution x=1500mm y=75mm




Example of a 107PE pulse




Example of a 105PE pulse




Example of a 153PE pulse




Example of a 131PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 204PE pulse




Example of a 207PE pulse




Example of a 182PE pulse




Example of a 173PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 100PE pulse




Example of a 82PE pulse




Example of a 125PE pulse




Example of a 111PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 42PE pulse




Example of a 25PE pulse




Example of a 291PE pulse




Example of a 258PE pulse




1293 PE distribution x=1500mm y=75mm




Example of a 64PE pulse




Example of a 76PE pulse




Example of a 209PE pulse




Example of a 191PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 112PE pulse




Example of a 27PE pulse




Example of a 85PE pulse




Example of a 77PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 70PE pulse




Example of a 69PE pulse



Example of a 167PE pulse




Example of a 161PE pulse







# 1293 PE distribution x=1500mm y=75mm




Example of a 72PE pulse




Example of a 89PE pulse




Example of a 217PE pulse




Example of a 194PE pulse




1293 PE distribution x=1500mm y=75mm




Example of a 112PE pulse




Example of a 100PE pulse




Example of a 137PE pulse




Example of a 129PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 203PE pulse




Example of a 194PE pulse




Example of a 199PE pulse




Example of a 174PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 68PE pulse




Example of a 62PE pulse




Example of a 120PE pulse




Example of a 97PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 31PE pulse




Example of a 35PE pulse




Example of a 251PE pulse




Example of a 267PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 92PE pulse




Example of a 94PE pulse




Example of a 175PE pulse




Example of a 159PE pulse




# 1293 PE distribution x=1500mm y=75mm




Example of a 27PE pulse




Example of a 27PE pulse




Example of a 94PE pulse




Example of a 77PE pulse




1293 PE distribution x=1500mm y=75mm




Example of a 85PE pulse



Example of a 63PE pulse



Example of a 154PE pulse



Example of a 183PE pulse

