




1269 PE distribution x=100mm y=25mm




Example of a 111PE pulse




Example of a 119PE pulse




Example of a 150PE pulse




Example of a 148PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 237PE pulse




Example of a 221PE pulse




Example of a 130PE pulse




Example of a 134PE pulse




1269 PE distribution x=100mm y=25mm




1269 PE distribution x=100mm y=25mm




1269 PE distribution x=100mm y=25mm




1269 PE distribution x=100mm y=25mm




1269 PE distribution x=100mm y=25mm




Example of a 99PE pulse




Example of a 74PE pulse




Example of a 88PE pulse




Example of a 85PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 207PE pulse




Example of a 210PE pulse




Example of a 125PE pulse




Example of a 131PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 48PE pulse




Example of a 47PE pulse




Example of a 74PE pulse




Example of a 95PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 129PE pulse




Example of a 153PE pulse




Example of a 65PE pulse




Example of a 69PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 78PE pulse




Example of a 76PE pulse




Example of a 33PE pulse




Example of a 23PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 75PE pulse




Example of a 68PE pulse




Example of a 36PE pulse




Example of a 36PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 58PE pulse




Example of a 66PE pulse




Example of a 54PE pulse




Example of a 67PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 189PE pulse




Example of a 149PE pulse




Example of a 118PE pulse




Example of a 91PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 45PE pulse




Example of a 62PE pulse




Example of a 55PE pulse




Example of a 41PE pulse




1269 PE distribution x=100mm y=25mm




Example of a 144PE pulse



Example of a 125PE pulse



Example of a 69PE pulse



Example of a 69PE pulse

