




833 PE distribution x=750mm y=75mm




Example of a 36PE pulse




Example of a 36PE pulse




Example of a 52PE pulse




Example of a 38PE pulse




833 PE distribution x=750mm y=75mm




Example of a 47PE pulse




Example of a 54PE pulse




Example of a 64PE pulse




Example of a 75PE pulse




833 PE distribution x=750mm y=75mm




Example of a 41PE pulse




Example of a 58PE pulse




Example of a 61PE pulse




Example of a 60PE pulse




833 PE distribution x=750mm y=75mm




Example of a 52PE pulse




Example of a 54PE pulse




Example of a 63PE pulse




Example of a 62PE pulse




833 PE distribution x=750mm y=75mm




Example of a 60PE pulse




Example of a 44PE pulse




Example of a 66PE pulse




Example of a 57PE pulse




833 PE distribution x=750mm y=75mm




Example of a 72PE pulse




Example of a 57PE pulse




Example of a 81PE pulse




Example of a 88PE pulse




833 PE distribution x=750mm y=75mm




Example of a 72PE pulse




Example of a 56PE pulse




Example of a 86PE pulse




Example of a 96PE pulse




833 PE distribution x=750mm y=75mm




Example of a 72PE pulse



Example of a 65PE pulse



Example of a 101PE pulse



Example of a 96PE pulse

