




1281 PE distribution x=75mm y=75mm




Example of a 116PE pulse




Example of a 126PE pulse




Example of a 212PE pulse




Example of a 162PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 103PE pulse




Example of a 79PE pulse




Example of a 141PE pulse




Example of a 119PE pulse




1281 PE distribution x=75mm y=75mm




1281 PE distribution x=75mm y=75mm




1281 PE distribution x=75mm y=75mm




1281 PE distribution x=75mm y=75mm




1281 PE distribution x=75mm y=75mm




Example of a 92PE pulse




Example of a 103PE pulse




Example of a 123PE pulse




Example of a 97PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 83PE pulse




Example of a 102PE pulse




Example of a 99PE pulse




Example of a 86PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 41PE pulse




Example of a 62PE pulse




Example of a 141PE pulse




Example of a 120PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 47PE pulse




Example of a 32PE pulse




Example of a 64PE pulse




Example of a 45PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 48PE pulse




Example of a 37PE pulse




Example of a 39PE pulse




Example of a 29PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 36PE pulse




Example of a 62PE pulse




Example of a 30PE pulse




Example of a 38PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 331PE pulse




Example of a 371PE pulse




Example of a 39PE pulse




Example of a 43PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 54PE pulse




Example of a 57PE pulse




Example of a 58PE pulse




Example of a 51PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 65PE pulse




Example of a 52PE pulse




Example of a 67PE pulse




Example of a 61PE pulse




1281 PE distribution x=75mm y=75mm




Example of a 58PE pulse



Example of a 63PE pulse



Example of a 45PE pulse



Example of a 37PE pulse

