




1068 PE distribution x=0mm y=25mm




Example of a 126PE pulse




Example of a 122PE pulse




Example of a 62PE pulse




Example of a 67PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 93PE pulse




Example of a 89PE pulse




Example of a 89PE pulse




Example of a 117PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 105PE pulse




Example of a 109PE pulse




Example of a 50PE pulse




Example of a 42PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 94PE pulse




Example of a 87PE pulse




Example of a 36PE pulse




Example of a 51PE pulse




1068 PE distribution x=0mm y=25mm




1068 PE distribution x=0mm y=25mm




1068 PE distribution x=0mm y=25mm




Example of a 171PE pulse




Example of a 196PE pulse




Example of a 120PE pulse




Example of a 113PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 69PE pulse




Example of a 80PE pulse




Example of a 82PE pulse




Example of a 111PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 38PE pulse




Example of a 42PE pulse




Example of a 25PE pulse




Example of a 31PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 48PE pulse




Example of a 62PE pulse




Example of a 54PE pulse




Example of a 81PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 226PE pulse




Example of a 233PE pulse




Example of a 26PE pulse




Example of a 20PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 74PE pulse




Example of a 55PE pulse




Example of a 46PE pulse




Example of a 49PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 188PE pulse




Example of a 177PE pulse




Example of a 25PE pulse




Example of a 25PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 62PE pulse




Example of a 45PE pulse




Example of a 21PE pulse




Example of a 23PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 224PE pulse




Example of a 215PE pulse




Example of a 57PE pulse




Example of a 48PE pulse




1068 PE distribution x=0mm y=25mm




Example of a 33PE pulse



Example of a 28PE pulse



Example of a 44PE pulse



Example of a 61PE pulse

