




1167 PE distribution x=0mm y=0mm




Example of a 126PE pulse




Example of a 101PE pulse




Example of a 101PE pulse




Example of a 141PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 106PE pulse




Example of a 180PE pulse




Example of a 117PE pulse




Example of a 99PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 126PE pulse




Example of a 97PE pulse




Example of a 100PE pulse




Example of a 104PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 118PE pulse




Example of a 36PE pulse




Example of a 115PE pulse




Example of a 88PE pulse




1167 PE distribution x=0mm y=0mm




1167 PE distribution x=0mm y=0mm




1167 PE distribution x=0mm y=0mm




Example of a 121PE pulse




Example of a 136PE pulse




Example of a 128PE pulse




Example of a 139PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 132PE pulse




Example of a 110PE pulse




Example of a 109PE pulse




Example of a 113PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 138PE pulse




Example of a 172PE pulse




Example of a 134PE pulse




Example of a 122PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 150PE pulse




Example of a 157PE pulse




Example of a 162PE pulse




Example of a 163PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 74PE pulse




Example of a 60PE pulse




Example of a 107PE pulse




Example of a 151PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 164PE pulse




Example of a 156PE pulse




Example of a 110PE pulse




Example of a 90PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 93PE pulse




Example of a 78PE pulse




Example of a 78PE pulse




Example of a 38PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 90PE pulse




Example of a 28PE pulse




Example of a 84PE pulse




Example of a 69PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 96PE pulse




Example of a 93PE pulse




Example of a 72PE pulse




Example of a 149PE pulse




1167 PE distribution x=0mm y=0mm




Example of a 124PE pulse



Example of a 123PE pulse



Example of a 108PE pulse



Example of a 93PE pulse

