




806 PE distribution x=1000mm y=75mm




Example of a 49PE pulse




Example of a 57PE pulse




Example of a 26PE pulse




Example of a 38PE pulse




806 PE distribution x=1000mm y=75mm




Example of a 68PE pulse




Example of a 58PE pulse




Example of a 51PE pulse




Example of a 60PE pulse




806 PE distribution x=1000mm y=75mm




Example of a 53PE pulse




Example of a 59PE pulse




Example of a 50PE pulse




Example of a 87PE pulse




806 PE distribution x=1000mm y=75mm




Example of a 56PE pulse




Example of a 72PE pulse




Example of a 74PE pulse




Example of a 85PE pulse




806 PE distribution x=1000mm y=75mm




Example of a 48PE pulse




Example of a 67PE pulse




Example of a 44PE pulse




Example of a 41PE pulse




806 PE distribution x=1000mm y=75mm




Example of a 75PE pulse




Example of a 75PE pulse




Example of a 63PE pulse




Example of a 65PE pulse




806 PE distribution x=1000mm y=75mm




Example of a 84PE pulse




Example of a 80PE pulse




Example of a 79PE pulse




Example of a 121PE pulse




806 PE distribution x=1000mm y=75mm




Example of a 79PE pulse



Example of a 80PE pulse



Example of a 84PE pulse



Example of a 119PE pulse

