




1069 PE distribution x=0mm y=75mm




Example of a 87PE pulse




Example of a 75PE pulse




Example of a 95PE pulse




Example of a 104PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 158PE pulse




Example of a 27PE pulse




Example of a 212PE pulse




Example of a 167PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 22PE pulse




Example of a 26PE pulse




Example of a 55PE pulse




Example of a 71PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 72PE pulse




Example of a 63PE pulse




Example of a 149PE pulse




Example of a 103PE pulse




1069 PE distribution x=0mm y=75mm




1069 PE distribution x=0mm y=75mm




1069 PE distribution x=0mm y=75mm




Example of a 154PE pulse




Example of a 166PE pulse




Example of a 65PE pulse




Example of a 84PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 116PE pulse




Example of a 87PE pulse




Example of a 164PE pulse




Example of a 155PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 179PE pulse




Example of a 134PE pulse




Example of a 52PE pulse




Example of a 92PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 205PE pulse




Example of a 213PE pulse




Example of a 156PE pulse




Example of a 99PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 210PE pulse




Example of a 197PE pulse




Example of a 50PE pulse




Example of a 64PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 78PE pulse




Example of a 91PE pulse




Example of a 107PE pulse




Example of a 99PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 115PE pulse




Example of a 22PE pulse




Example of a 27PE pulse




Example of a 39PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 39PE pulse




Example of a 32PE pulse




Example of a 102PE pulse




Example of a 81PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 87PE pulse




Example of a 96PE pulse




Example of a 40PE pulse




Example of a 61PE pulse




1069 PE distribution x=0mm y=75mm




Example of a 51PE pulse



Example of a 55PE pulse



Example of a 116PE pulse



Example of a 106PE pulse

