




# 1166 PE distribution x=0mm y=0mm




Example of a 104PE pulse




Example of a 88PE pulse




Example of a 138PE pulse




Example of a 141PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 86PE pulse




Example of a 86PE pulse




Example of a 79PE pulse




Example of a 109PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 214PE pulse




Example of a 189PE pulse




Example of a 158PE pulse




Example of a 185PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 117PE pulse




Example of a 105PE pulse




Example of a 98PE pulse




Example of a 118PE pulse




# 1166 PE distribution x=0mm y=0mm




# 1166 PE distribution x=0mm y=0mm




# 1166 PE distribution x=0mm y=0mm




Example of a 61PE pulse




Example of a 43PE pulse




Example of a 99PE pulse




Example of a 106PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 196PE pulse




Example of a 186PE pulse



Example of a 80PE pulse




Example of a 113PE pulse







# 1166 PE distribution x=0mm y=0mm




Example of a 140PE pulse




Example of a 122PE pulse




Example of a 91PE pulse




Example of a 120PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 137PE pulse




Example of a 151PE pulse




Example of a 148PE pulse




Example of a 169PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 154PE pulse




Example of a 149PE pulse




Example of a 93PE pulse




Example of a 106PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 79PE pulse




Example of a 87PE pulse




Example of a 76PE pulse




Example of a 97PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 164PE pulse




Example of a 182PE pulse




Example of a 119PE pulse




Example of a 157PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 94PE pulse




Example of a 84PE pulse




Example of a 93PE pulse




Example of a 73PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 99PE pulse




Example of a 33PE pulse




Example of a 54PE pulse




Example of a 83PE pulse




# 1166 PE distribution x=0mm y=0mm




Example of a 179PE pulse



Example of a 168PE pulse



Example of a 81PE pulse



Example of a 109PE pulse

