




1029 PE distribution x=1250mm y=25mm




Example of a 218PE pulse




Example of a 187PE pulse




Example of a 86PE pulse




Example of a 76PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 85PE pulse




Example of a 72PE pulse




Example of a 112PE pulse




Example of a 100PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 79PE pulse




Example of a 89PE pulse




Example of a 109PE pulse




Example of a 97PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 76PE pulse




Example of a 56PE pulse




Example of a 143PE pulse




Example of a 153PE pulse




1029 PE distribution x=1250mm y=25mm




1029 PE distribution x=1250mm y=25mm




1029 PE distribution x=1250mm y=25mm




Example of a 169PE pulse




Example of a 109PE pulse




Example of a 157PE pulse




Example of a 145PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 56PE pulse




Example of a 68PE pulse




Example of a 67PE pulse




Example of a 76PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 159PE pulse




Example of a 198PE pulse




Example of a 82PE pulse




Example of a 75PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 73PE pulse




Example of a 77PE pulse




Example of a 52PE pulse




Example of a 88PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 90PE pulse




Example of a 55PE pulse




Example of a 80PE pulse




Example of a 103PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 61PE pulse




Example of a 84PE pulse




Example of a 140PE pulse




Example of a 134PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 85PE pulse




Example of a 440PE pulse




Example of a 49PE pulse




Example of a 94PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 172PE pulse




Example of a 125PE pulse




Example of a 84PE pulse




Example of a 95PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 55PE pulse




Example of a 59PE pulse




Example of a 63PE pulse




Example of a 62PE pulse




1029 PE distribution x=1250mm y=25mm




Example of a 85PE pulse



Example of a 67PE pulse



Example of a 66PE pulse



Example of a 70PE pulse

