




1174 PE distribution x=1000mm y=25mm




Example of a 101PE pulse




Example of a 93PE pulse




Example of a 112PE pulse




Example of a 88PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 80PE pulse




Example of a 105PE pulse




Example of a 104PE pulse




Example of a 78PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 105PE pulse




Example of a 85PE pulse




Example of a 151PE pulse




Example of a 136PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 166PE pulse




Example of a 155PE pulse




Example of a 125PE pulse




Example of a 109PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 22PE pulse




Example of a 21PE pulse




Example of a 20PE pulse




Example of a 25PE pulse




1174 PE distribution x=1000mm y=25mm




1174 PE distribution x=1000mm y=25mm




Example of a 103PE pulse




Example of a 109PE pulse




Example of a 117PE pulse




Example of a 114PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 31PE pulse




Example of a 53PE pulse




Example of a 135PE pulse




Example of a 111PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 130PE pulse




Example of a 125PE pulse




Example of a 129PE pulse




Example of a 109PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 189PE pulse




Example of a 231PE pulse




Example of a 151PE pulse




Example of a 118PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 83PE pulse




Example of a 86PE pulse




Example of a 94PE pulse




Example of a 93PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 66PE pulse




Example of a 22PE pulse




Example of a 60PE pulse




Example of a 63PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 113PE pulse




Example of a 100PE pulse




Example of a 122PE pulse




Example of a 141PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 165PE pulse




Example of a 133PE pulse




Example of a 109PE pulse




Example of a 104PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 94PE pulse




Example of a 123PE pulse




Example of a 100PE pulse




Example of a 67PE pulse




1174 PE distribution x=1000mm y=25mm




Example of a 45PE pulse



Example of a 25PE pulse



Example of a 137PE pulse



Example of a 107PE pulse

