




1056 PE distribution x=300mm y=75mm




Example of a 78PE pulse




Example of a 92PE pulse




Example of a 181PE pulse




Example of a 157PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 79PE pulse




Example of a 97PE pulse




Example of a 105PE pulse




Example of a 110PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 164PE pulse




Example of a 146PE pulse




Example of a 163PE pulse




Example of a 176PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 88PE pulse




Example of a 77PE pulse




Example of a 83PE pulse




Example of a 100PE pulse




1056 PE distribution x=300mm y=75mm




1056 PE distribution x=300mm y=75mm




1056 PE distribution x=300mm y=75mm




Example of a 92PE pulse




Example of a 76PE pulse




Example of a 160PE pulse




Example of a 146PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 84PE pulse




Example of a 87PE pulse




Example of a 99PE pulse




Example of a 81PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 163PE pulse




Example of a 155PE pulse




Example of a 231PE pulse




Example of a 177PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 104PE pulse




Example of a 89PE pulse




Example of a 156PE pulse




Example of a 123PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 47PE pulse




Example of a 54PE pulse




Example of a 126PE pulse




Example of a 93PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 52PE pulse




Example of a 59PE pulse




Example of a 59PE pulse




Example of a 60PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 81PE pulse




Example of a 97PE pulse




Example of a 133PE pulse




Example of a 107PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 45PE pulse




Example of a 48PE pulse




Example of a 47PE pulse




Example of a 54PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 57PE pulse




Example of a 47PE pulse




Example of a 100PE pulse




Example of a 101PE pulse




1056 PE distribution x=300mm y=75mm




Example of a 59PE pulse



Example of a 38PE pulse



Example of a 64PE pulse



Example of a 49PE pulse

