




# 826 PE distribution x=1750mm y=25mm




Example of a 40PE pulse




Example of a 54PE pulse




Example of a 40PE pulse




Example of a 57PE pulse




# 826 PE distribution x=1750mm y=25mm




Example of a 54PE pulse




Example of a 51PE pulse




Example of a 61PE pulse




Example of a 60PE pulse




# 826 PE distribution x=1750mm y=25mm




Example of a 40PE pulse




Example of a 51PE pulse




Example of a 87PE pulse




Example of a 82PE pulse




# 826 PE distribution x=1750mm y=25mm




Example of a 71PE pulse




Example of a 71PE pulse




Example of a 71PE pulse




Example of a 93PE pulse




# 826 PE distribution x=1750mm y=25mm




Example of a 37PE pulse




Example of a 51PE pulse




Example of a 45PE pulse




Example of a 54PE pulse




# 826 PE distribution x=1750mm y=25mm




Example of a 57PE pulse




Example of a 57PE pulse




Example of a 62PE pulse




Example of a 58PE pulse




# 826 PE distribution x=1750mm y=25mm




Example of a 53PE pulse




Example of a 74PE pulse




Example of a 74PE pulse




Example of a 86PE pulse




# 826 PE distribution x=1750mm y=25mm




Example of a 51PE pulse



Example of a 65PE pulse



Example of a 74PE pulse



Example of a 106PE pulse

