




1159 PE distribution x=1000mm y=75mm




Example of a 220PE pulse




Example of a 203PE pulse




Example of a 184PE pulse




Example of a 126PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 57PE pulse




Example of a 55PE pulse




Example of a 145PE pulse




Example of a 143PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 287PE pulse




Example of a 265PE pulse




Example of a 130PE pulse




Example of a 119PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 70PE pulse




Example of a 71PE pulse




Example of a 72PE pulse




Example of a 59PE pulse




1159 PE distribution x=1000mm y=75mm




1159 PE distribution x=1000mm y=75mm




1159 PE distribution x=1000mm y=75mm




Example of a 225PE pulse




Example of a 258PE pulse




Example of a 34PE pulse




Example of a 29PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 78PE pulse




Example of a 68PE pulse




Example of a 96PE pulse




Example of a 69PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 52PE pulse




Example of a 89PE pulse




Example of a 171PE pulse




Example of a 170PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 142PE pulse




Example of a 100PE pulse




Example of a 159PE pulse




Example of a 121PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 201PE pulse




Example of a 196PE pulse




Example of a 122PE pulse




Example of a 140PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 70PE pulse




Example of a 67PE pulse




Example of a 159PE pulse




Example of a 129PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 68PE pulse




Example of a 86PE pulse




Example of a 142PE pulse




Example of a 135PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 79PE pulse




Example of a 61PE pulse




Example of a 79PE pulse




Example of a 49PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 80PE pulse




Example of a 61PE pulse




Example of a 181PE pulse




Example of a 37PE pulse




1159 PE distribution x=1000mm y=75mm




Example of a 92PE pulse



Example of a 88PE pulse



Example of a 70PE pulse



Example of a 82PE pulse

