




1275 PE distribution x=0mm y=25mm




Example of a 79PE pulse




Example of a 121PE pulse




Example of a 20PE pulse




Example of a 22PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 126PE pulse




Example of a 107PE pulse




Example of a 177PE pulse




Example of a 175PE pulse




1275 PE distribution x=0mm y=25mm




1275 PE distribution x=0mm y=25mm




1275 PE distribution x=0mm y=25mm




1275 PE distribution x=0mm y=25mm




1275 PE distribution x=0mm y=25mm




Example of a 85PE pulse




Example of a 83PE pulse




Example of a 21PE pulse




Example of a 32PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 62PE pulse




Example of a 84PE pulse




Example of a 91PE pulse




Example of a 87PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 47PE pulse




Example of a 48PE pulse




Example of a 46PE pulse




Example of a 66PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 55PE pulse




Example of a 43PE pulse




Example of a 108PE pulse




Example of a 83PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 29PE pulse




Example of a 29PE pulse




Example of a 87PE pulse




Example of a 67PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 24PE pulse




Example of a 36PE pulse




Example of a 26PE pulse




Example of a 41PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 38PE pulse




Example of a 55PE pulse




Example of a 103PE pulse




Example of a 110PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 100PE pulse




Example of a 46PE pulse




Example of a 39PE pulse




Example of a 29PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 54PE pulse




Example of a 41PE pulse




Example of a 237PE pulse




Example of a 269PE pulse




1275 PE distribution x=0mm y=25mm




Example of a 36PE pulse



Example of a 43PE pulse



Example of a 47PE pulse



Example of a 49PE pulse

