




1251 PE distribution x=1000mm y=75mm




Example of a 92PE pulse




Example of a 75PE pulse




Example of a 98PE pulse




Example of a 105PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 88PE pulse




Example of a 88PE pulse




Example of a 98PE pulse




Example of a 92PE pulse




1251 PE distribution x=1000mm y=75mm




1251 PE distribution x=1000mm y=75mm




1251 PE distribution x=1000mm y=75mm




Example of a 24PE pulse




Example of a 29PE pulse




Example of a 20PE pulse




1251 PE distribution x=1000mm y=75mm




1251 PE distribution x=1000mm y=75mm




Example of a 237PE pulse




Example of a 197PE pulse




Example of a 130PE pulse




Example of a 102PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 64PE pulse




Example of a 76PE pulse




Example of a 139PE pulse




Example of a 148PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 107PE pulse




Example of a 56PE pulse




Example of a 94PE pulse




Example of a 55PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 74PE pulse




Example of a 68PE pulse




Example of a 61PE pulse




Example of a 63PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 279PE pulse




Example of a 251PE pulse




Example of a 72PE pulse




Example of a 49PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 72PE pulse




Example of a 57PE pulse




Example of a 55PE pulse




Example of a 70PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 102PE pulse




Example of a 124PE pulse




Example of a 118PE pulse




Example of a 86PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 86PE pulse




Example of a 59PE pulse




Example of a 179PE pulse




Example of a 134PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 203PE pulse




Example of a 163PE pulse




Example of a 96PE pulse




Example of a 87PE pulse




1251 PE distribution x=1000mm y=75mm




Example of a 50PE pulse



Example of a 46PE pulse



Example of a 142PE pulse



Example of a 117PE pulse

