




# 1046 PE distribution x=50mm y=25mm




Example of a 64PE pulse




Example of a 81PE pulse




Example of a 103PE pulse




Example of a 84PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 79PE pulse




Example of a 68PE pulse




Example of a 159PE pulse




Example of a 182PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 57PE pulse




Example of a 55PE pulse




Example of a 71PE pulse




Example of a 67PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 81PE pulse




Example of a 63PE pulse




Example of a 24PE pulse




Example of a 31PE pulse




# 1046 PE distribution x=50mm y=25mm




# 1046 PE distribution x=50mm y=25mm




# 1046 PE distribution x=50mm y=25mm




Example of a 99PE pulse




Example of a 78PE pulse




Example of a 83PE pulse




Example of a 82PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 136PE pulse




Example of a 137PE pulse



Example of a 154PE pulse




Example of a 200PE pulse







# 1046 PE distribution x=50mm y=25mm




Example of a 116PE pulse




Example of a 89PE pulse




Example of a 60PE pulse




Example of a 56PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 210PE pulse




Example of a 24PE pulse




Example of a 59PE pulse




Example of a 84PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 52PE pulse




Example of a 35PE pulse




Example of a 39PE pulse




Example of a 34PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 79PE pulse




Example of a 79PE pulse




Example of a 249PE pulse




Example of a 242PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 34PE pulse




Example of a 41PE pulse




Example of a 26PE pulse




Example of a 38PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 220PE pulse




Example of a 244PE pulse




Example of a 215PE pulse




Example of a 205PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 38PE pulse




Example of a 50PE pulse




Example of a 46PE pulse




Example of a 37PE pulse




# 1046 PE distribution x=50mm y=25mm




Example of a 72PE pulse



Example of a 86PE pulse



Example of a 123PE pulse



Example of a 267PE pulse

