




# 1161 PE distribution x=0mm y=0mm




Example of a 74PE pulse




Example of a 74PE pulse




Example of a 84PE pulse




Example of a 68PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 193PE pulse




Example of a 146PE pulse




Example of a 255PE pulse




Example of a 251PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 77PE pulse




Example of a 90PE pulse




Example of a 70PE pulse




Example of a 76PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 162PE pulse




Example of a 153PE pulse




Example of a 94PE pulse




Example of a 134PE pulse




# 1161 PE distribution x=0mm y=0mm




# 1161 PE distribution x=0mm y=0mm




# 1161 PE distribution x=0mm y=0mm




Example of a 88PE pulse




Example of a 97PE pulse




Example of a 99PE pulse




Example of a 106PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 100PE pulse




Example of a 95PE pulse



Example of a 151PE pulse




Example of a 161PE pulse







# 1161 PE distribution x=0mm y=0mm




Example of a 129PE pulse




Example of a 131PE pulse




Example of a 152PE pulse




Example of a 131PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 103PE pulse




Example of a 58PE pulse




Example of a 36PE pulse




Example of a 55PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 76PE pulse




Example of a 75PE pulse




Example of a 78PE pulse




Example of a 52PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 171PE pulse




Example of a 162PE pulse




Example of a 214PE pulse




Example of a 203PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 69PE pulse




Example of a 96PE pulse




Example of a 86PE pulse




Example of a 91PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 163PE pulse




Example of a 148PE pulse




Example of a 119PE pulse




Example of a 107PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 89PE pulse




Example of a 89PE pulse




Example of a 103PE pulse




Example of a 98PE pulse




# 1161 PE distribution x=0mm y=0mm




Example of a 105PE pulse



Example of a 106PE pulse



Example of a 122PE pulse



Example of a 133PE pulse

