




# 1022 PE distribution x=50mm y=25mm




Example of a 104PE pulse




Example of a 98PE pulse




Example of a 101PE pulse




Example of a 87PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 130PE pulse




Example of a 153PE pulse




Example of a 161PE pulse




Example of a 196PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 75PE pulse




Example of a 55PE pulse




Example of a 80PE pulse




Example of a 60PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 80PE pulse




Example of a 95PE pulse




Example of a 137PE pulse




Example of a 135PE pulse




# 1022 PE distribution x=50mm y=25mm




# 1022 PE distribution x=50mm y=25mm




# 1022 PE distribution x=50mm y=25mm




Example of a 114PE pulse




Example of a 130PE pulse




Example of a 166PE pulse




Example of a 111PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 335PE pulse




Example of a 24PE pulse



Example of a 25PE pulse




Example of a 168PE pulse







# 1022 PE distribution x=50mm y=25mm




Example of a 52PE pulse




Example of a 45PE pulse




Example of a 51PE pulse




Example of a 44PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 59PE pulse




Example of a 59PE pulse




Example of a 94PE pulse




Example of a 92PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 30PE pulse




Example of a 21PE pulse




Example of a 41PE pulse




Example of a 53PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 35PE pulse




Example of a 39PE pulse




Example of a 57PE pulse




Example of a 66PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 41PE pulse




Example of a 53PE pulse




Example of a 47PE pulse




Example of a 59PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 56PE pulse




Example of a 61PE pulse




Example of a 77PE pulse




Example of a 90PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 39PE pulse




Example of a 27PE pulse




Example of a 45PE pulse




Example of a 39PE pulse




# 1022 PE distribution x=50mm y=25mm




Example of a 121PE pulse



Example of a 130PE pulse



Example of a 72PE pulse



Example of a 67PE pulse

