




1259 PE distribution x=1750mm y=25mm




Example of a 81PE pulse




Example of a 59PE pulse




Example of a 88PE pulse




Example of a 73PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 183PE pulse




Example of a 159PE pulse




Example of a 82PE pulse




Example of a 94PE pulse




1259 PE distribution x=1750mm y=25mm




1259 PE distribution x=1750mm y=25mm




1259 PE distribution x=1750mm y=25mm




Example of a 20PE pulse




1259 PE distribution x=1750mm y=25mm




1259 PE distribution x=1750mm y=25mm




Example of a 72PE pulse




Example of a 69PE pulse




Example of a 66PE pulse




Example of a 69PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 146PE pulse




Example of a 140PE pulse




Example of a 127PE pulse




Example of a 162PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 76PE pulse




Example of a 68PE pulse




Example of a 84PE pulse




Example of a 83PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 198PE pulse




Example of a 190PE pulse




Example of a 88PE pulse




Example of a 97PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 100PE pulse




Example of a 96PE pulse




Example of a 80PE pulse




Example of a 56PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 167PE pulse




Example of a 25PE pulse




Example of a 58PE pulse




Example of a 84PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 96PE pulse




Example of a 108PE pulse




Example of a 75PE pulse




Example of a 95PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 194PE pulse




Example of a 177PE pulse




Example of a 101PE pulse




Example of a 140PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 71PE pulse




Example of a 61PE pulse




Example of a 104PE pulse




Example of a 114PE pulse




1259 PE distribution x=1750mm y=25mm




Example of a 137PE pulse



Example of a 156PE pulse



Example of a 161PE pulse



Example of a 177PE pulse

