




1047 PE distribution x=20mm y=25mm




Example of a 43PE pulse




Example of a 49PE pulse




Example of a 60PE pulse




Example of a 46PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 72PE pulse




Example of a 72PE pulse




Example of a 112PE pulse




Example of a 84PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 65PE pulse




Example of a 49PE pulse




Example of a 59PE pulse




Example of a 40PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 262PE pulse




Example of a 234PE pulse




Example of a 175PE pulse




Example of a 194PE pulse




1047 PE distribution x=20mm y=25mm




1047 PE distribution x=20mm y=25mm




1047 PE distribution x=20mm y=25mm




Example of a 73PE pulse




Example of a 56PE pulse




Example of a 81PE pulse




Example of a 79PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 75PE pulse




Example of a 76PE pulse




Example of a 240PE pulse




Example of a 219PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 40PE pulse




Example of a 53PE pulse




Example of a 45PE pulse




Example of a 45PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 97PE pulse




Example of a 75PE pulse




Example of a 210PE pulse




Example of a 207PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 27PE pulse




Example of a 24PE pulse




Example of a 25PE pulse




Example of a 25PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 58PE pulse




Example of a 44PE pulse




Example of a 127PE pulse




Example of a 158PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 27PE pulse




Example of a 34PE pulse




Example of a 21PE pulse




Example of a 21PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 146PE pulse




Example of a 111PE pulse




Example of a 80PE pulse




Example of a 103PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 41PE pulse




Example of a 49PE pulse




Example of a 44PE pulse




Example of a 33PE pulse




1047 PE distribution x=20mm y=25mm




Example of a 59PE pulse



Example of a 52PE pulse



Example of a 122PE pulse



Example of a 133PE pulse

