




816 PE distribution x=2000mm y=25mm




Example of a 196PE pulse




Example of a 173PE pulse




Example of a 74PE pulse




Example of a 66PE pulse




816 PE distribution x=2000mm y=25mm




Example of a 68PE pulse




Example of a 73PE pulse




Example of a 65PE pulse




Example of a 61PE pulse




816 PE distribution x=2000mm y=25mm




Example of a 90PE pulse




Example of a 69PE pulse




Example of a 65PE pulse




Example of a 63PE pulse




816 PE distribution x=2000mm y=25mm




Example of a 91PE pulse




Example of a 58PE pulse




Example of a 71PE pulse




Example of a 92PE pulse




816 PE distribution x=2000mm y=25mm




Example of a 182PE pulse




Example of a 160PE pulse




Example of a 71PE pulse




Example of a 64PE pulse




816 PE distribution x=2000mm y=25mm




Example of a 47PE pulse




Example of a 223PE pulse




Example of a 43PE pulse




Example of a 54PE pulse




816 PE distribution x=2000mm y=25mm




Example of a 70PE pulse




Example of a 51PE pulse




Example of a 64PE pulse




Example of a 52PE pulse




816 PE distribution x=2000mm y=25mm




Example of a 70PE pulse



Example of a 68PE pulse



Example of a 63PE pulse



Example of a 66PE pulse

