




1328 PE distribution x=1750mm y=25mm




Example of a 119PE pulse




Example of a 79PE pulse




Example of a 69PE pulse




Example of a 67PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 294PE pulse




Example of a 232PE pulse




Example of a 85PE pulse




Example of a 82PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 68PE pulse




Example of a 63PE pulse




Example of a 49PE pulse




Example of a 53PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 202PE pulse




Example of a 177PE pulse




Example of a 54PE pulse




Example of a 52PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 69PE pulse




Example of a 66PE pulse




Example of a 38PE pulse




Example of a 43PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 275PE pulse




Example of a 261PE pulse




Example of a 49PE pulse




Example of a 51PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 74PE pulse




Example of a 56PE pulse




Example of a 46PE pulse




Example of a 50PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 161PE pulse




Example of a 210PE pulse




Example of a 41PE pulse




Example of a 49PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 125PE pulse




Example of a 97PE pulse




Example of a 84PE pulse




Example of a 72PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 87PE pulse




Example of a 259PE pulse




Example of a 75PE pulse




Example of a 88PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 83PE pulse




Example of a 60PE pulse




Example of a 53PE pulse




Example of a 59PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 260PE pulse




Example of a 224PE pulse




Example of a 58PE pulse




Example of a 59PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 79PE pulse




Example of a 47PE pulse




Example of a 60PE pulse




Example of a 61PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 309PE pulse




Example of a 274PE pulse




Example of a 60PE pulse




Example of a 50PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 58PE pulse




Example of a 36PE pulse




Example of a 30PE pulse




Example of a 52PE pulse




1328 PE distribution x=1750mm y=25mm




Example of a 23PE pulse



Example of a 29PE pulse



Example of a 36PE pulse



Example of a 31PE pulse

