




1158 PE distribution x=1000mm y=75mm




Example of a 85PE pulse




Example of a 69PE pulse




Example of a 124PE pulse




Example of a 115PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 80PE pulse




Example of a 70PE pulse




Example of a 104PE pulse




Example of a 73PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 163PE pulse




Example of a 143PE pulse




Example of a 112PE pulse




Example of a 121PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 63PE pulse




Example of a 80PE pulse




Example of a 116PE pulse




Example of a 86PE pulse




1158 PE distribution x=1000mm y=75mm




1158 PE distribution x=1000mm y=75mm




1158 PE distribution x=1000mm y=75mm




Example of a 114PE pulse




Example of a 118PE pulse




Example of a 173PE pulse




Example of a 153PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 86PE pulse




Example of a 91PE pulse




Example of a 86PE pulse




Example of a 57PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 24PE pulse




Example of a 33PE pulse




Example of a 168PE pulse




Example of a 145PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 116PE pulse




Example of a 97PE pulse




Example of a 130PE pulse




Example of a 130PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 72PE pulse




Example of a 47PE pulse




Example of a 97PE pulse




Example of a 69PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 62PE pulse




Example of a 61PE pulse




Example of a 79PE pulse




Example of a 54PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 106PE pulse




Example of a 97PE pulse




Example of a 96PE pulse




Example of a 102PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 82PE pulse




Example of a 69PE pulse




Example of a 92PE pulse




Example of a 94PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 97PE pulse




Example of a 91PE pulse




Example of a 135PE pulse




Example of a 122PE pulse




1158 PE distribution x=1000mm y=75mm




Example of a 79PE pulse



Example of a 80PE pulse



Example of a 73PE pulse



Example of a 64PE pulse

