




# 1028 PE distribution x=1000mm y=25mm




Example of a 98PE pulse




Example of a 90PE pulse




Example of a 96PE pulse




Example of a 80PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 106PE pulse




Example of a 99PE pulse




Example of a 230PE pulse




Example of a 224PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 77PE pulse




Example of a 68PE pulse




Example of a 92PE pulse




Example of a 103PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 144PE pulse




Example of a 130PE pulse




Example of a 237PE pulse




Example of a 252PE pulse




1028 PE distribution x=1000mm y=25mm




1028 PE distribution x=1000mm y=25mm




# 1028 PE distribution x=1000mm y=25mm




Example of a 132PE pulse




Example of a 168PE pulse




Example of a 106PE pulse




Example of a 140PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 340PE pulse




Example of a 89PE pulse



Example of a 111PE pulse




Example of a 237PE pulse







# 1028 PE distribution x=1000mm y=25mm




Example of a 79PE pulse




Example of a 63PE pulse




Example of a 78PE pulse




Example of a 66PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 83PE pulse




Example of a 73PE pulse




Example of a 174PE pulse




Example of a 190PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 66PE pulse




Example of a 75PE pulse




Example of a 88PE pulse




Example of a 78PE pulse




1028 PE distribution x=1000mm y=25mm




Example of a 104PE pulse




Example of a 105PE pulse




Example of a 182PE pulse




Example of a 212PE pulse




1028 PE distribution x=1000mm y=25mm




Example of a 87PE pulse




Example of a 251PE pulse




Example of a 45PE pulse




Example of a 100PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 102PE pulse




Example of a 83PE pulse




Example of a 175PE pulse




Example of a 160PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 68PE pulse




Example of a 76PE pulse




Example of a 48PE pulse




Example of a 50PE pulse




# 1028 PE distribution x=1000mm y=25mm




Example of a 48PE pulse



Example of a 54PE pulse



Example of a 167PE pulse



Example of a 166PE pulse

