




1045 PE distribution x=100mm y=25mm




Example of a 95PE pulse




Example of a 80PE pulse




Example of a 95PE pulse




Example of a 110PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 147PE pulse




Example of a 166PE pulse




Example of a 140PE pulse




Example of a 156PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 84PE pulse




Example of a 72PE pulse




Example of a 148PE pulse




Example of a 121PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 68PE pulse




Example of a 71PE pulse




Example of a 140PE pulse




Example of a 136PE pulse




1045 PE distribution x=100mm y=25mm




1045 PE distribution x=100mm y=25mm




1045 PE distribution x=100mm y=25mm




Example of a 98PE pulse




Example of a 73PE pulse




Example of a 77PE pulse




Example of a 88PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 154PE pulse




Example of a 173PE pulse




Example of a 244PE pulse




Example of a 292PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 81PE pulse




Example of a 94PE pulse




Example of a 90PE pulse




Example of a 91PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 93PE pulse




Example of a 94PE pulse




Example of a 147PE pulse




Example of a 143PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 48PE pulse




Example of a 47PE pulse




Example of a 58PE pulse




Example of a 44PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 58PE pulse




Example of a 85PE pulse




Example of a 73PE pulse




Example of a 68PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 64PE pulse




Example of a 41PE pulse




Example of a 63PE pulse




Example of a 81PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 36PE pulse




Example of a 44PE pulse




Example of a 61PE pulse




Example of a 74PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 30PE pulse




Example of a 52PE pulse




Example of a 50PE pulse




Example of a 52PE pulse




1045 PE distribution x=100mm y=25mm




Example of a 103PE pulse



Example of a 96PE pulse



Example of a 152PE pulse



Example of a 169PE pulse

