




824 PE distribution x=2000mm y=75mm




Example of a 59PE pulse




Example of a 64PE pulse




Example of a 47PE pulse




Example of a 45PE pulse




824 PE distribution x=2000mm y=75mm




Example of a 111PE pulse




Example of a 124PE pulse




Example of a 68PE pulse




Example of a 89PE pulse




824 PE distribution x=2000mm y=75mm




Example of a 134PE pulse




Example of a 136PE pulse




Example of a 89PE pulse




Example of a 96PE pulse




824 PE distribution x=2000mm y=75mm




Example of a 80PE pulse




Example of a 84PE pulse




Example of a 76PE pulse




Example of a 92PE pulse




824 PE distribution x=2000mm y=75mm




Example of a 48PE pulse




Example of a 50PE pulse




Example of a 47PE pulse




Example of a 42PE pulse




824 PE distribution x=2000mm y=75mm




Example of a 115PE pulse




Example of a 91PE pulse




Example of a 58PE pulse




Example of a 49PE pulse




824 PE distribution x=2000mm y=75mm




Example of a 122PE pulse




Example of a 111PE pulse




Example of a 64PE pulse




Example of a 71PE pulse




824 PE distribution x=2000mm y=75mm




Example of a 58PE pulse



Example of a 75PE pulse



Example of a 71PE pulse



Example of a 55PE pulse

