




1172 PE distribution x=1000mm y=75mm




Example of a 84PE pulse




Example of a 113PE pulse




Example of a 100PE pulse




Example of a 114PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 138PE pulse




Example of a 186PE pulse




Example of a 140PE pulse




Example of a 128PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 176PE pulse




Example of a 140PE pulse




Example of a 131PE pulse




Example of a 88PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 115PE pulse




Example of a 129PE pulse




Example of a 194PE pulse




Example of a 111PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 20PE pulse




Example of a 22PE pulse




Example of a 29PE pulse




Example of a 25PE pulse




1172 PE distribution x=1000mm y=75mm




1172 PE distribution x=1000mm y=75mm




Example of a 130PE pulse




Example of a 188PE pulse




Example of a 184PE pulse




Example of a 143PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 112PE pulse




Example of a 100PE pulse




Example of a 102PE pulse




Example of a 99PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 199PE pulse




Example of a 27PE pulse




Example of a 187PE pulse




Example of a 146PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 163PE pulse




Example of a 200PE pulse




Example of a 151PE pulse




Example of a 140PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 85PE pulse




Example of a 105PE pulse




Example of a 102PE pulse




Example of a 98PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 145PE pulse




Example of a 170PE pulse




Example of a 101PE pulse




Example of a 129PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 103PE pulse




Example of a 125PE pulse




Example of a 122PE pulse




Example of a 136PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 84PE pulse




Example of a 84PE pulse




Example of a 124PE pulse




Example of a 114PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 37PE pulse




Example of a 21PE pulse




Example of a 165PE pulse




Example of a 141PE pulse




1172 PE distribution x=1000mm y=75mm




Example of a 139PE pulse



Example of a 151PE pulse



Example of a 115PE pulse



Example of a 106PE pulse

