




1340 PE distribution x=750mm y=25mm




Example of a 105PE pulse




Example of a 115PE pulse




Example of a 88PE pulse




Example of a 65PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 110PE pulse




Example of a 83PE pulse




Example of a 153PE pulse




Example of a 171PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 56PE pulse




Example of a 50PE pulse




Example of a 46PE pulse




Example of a 37PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 115PE pulse




Example of a 112PE pulse




Example of a 44PE pulse




Example of a 32PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 63PE pulse




Example of a 70PE pulse




Example of a 313PE pulse




Example of a 270PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 123PE pulse




Example of a 151PE pulse




Example of a 221PE pulse




Example of a 246PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 74PE pulse




Example of a 58PE pulse




Example of a 77PE pulse




Example of a 62PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 53PE pulse




Example of a 107PE pulse




Example of a 163PE pulse




Example of a 289PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 77PE pulse




Example of a 66PE pulse




Example of a 67PE pulse




Example of a 36PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 66PE pulse




Example of a 45PE pulse




Example of a 110PE pulse




Example of a 132PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 47PE pulse




Example of a 32PE pulse




Example of a 57PE pulse




Example of a 33PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 77PE pulse




Example of a 81PE pulse




Example of a 36PE pulse




Example of a 28PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 52PE pulse




Example of a 55PE pulse




Example of a 243PE pulse




Example of a 211PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 95PE pulse




Example of a 95PE pulse




Example of a 163PE pulse




Example of a 216PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 34PE pulse




Example of a 41PE pulse




Example of a 43PE pulse




Example of a 26PE pulse




1340 PE distribution x=750mm y=25mm




Example of a 57PE pulse



Example of a 81PE pulse



Example of a 28PE pulse



Example of a 25PE pulse

