




# 710 PE distribution x=60mm y=25mm




Example of a 45PE pulse




Example of a 46PE pulse




Example of a 48PE pulse




Example of a 50PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 75PE pulse




Example of a 36PE pulse




Example of a 31PE pulse




Example of a 53PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 30PE pulse




Example of a 35PE pulse




Example of a 46PE pulse




Example of a 36PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 29PE pulse




Example of a 33PE pulse




Example of a 34PE pulse




Example of a 63PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 63PE pulse




Example of a 54PE pulse




Example of a 62PE pulse




Example of a 54PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 39PE pulse




Example of a 51PE pulse




Example of a 38PE pulse




Example of a 53PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 37PE pulse




Example of a 47PE pulse




Example of a 34PE pulse




Example of a 41PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 46PE pulse




Example of a 77PE pulse



Example of a 85PE pulse




Example of a 211PE pulse







# 710 PE distribution x=60mm y=25mm




Example of a 69PE pulse




Example of a 79PE pulse




Example of a 80PE pulse




Example of a 81PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 39PE pulse




Example of a 72PE pulse




Example of a 75PE pulse




Example of a 97PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 87PE pulse




Example of a 53PE pulse




Example of a 48PE pulse




Example of a 52PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 57PE pulse




Example of a 58PE pulse




Example of a 68PE pulse




Example of a 85PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 79PE pulse




Example of a 101PE pulse




Example of a 85PE pulse




Example of a 68PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 73PE pulse




Example of a 86PE pulse




Example of a 70PE pulse




Example of a 92PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 28PE pulse




Example of a 38PE pulse




Example of a 64PE pulse




Example of a 65PE pulse




# 710 PE distribution x=60mm y=25mm




Example of a 35PE pulse



Example of a 53PE pulse



Example of a 31PE pulse



Example of a 28PE pulse

