




# 1023 PE distribution x=100mm y=25mm




Example of a 141PE pulse




Example of a 129PE pulse




Example of a 83PE pulse




Example of a 80PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 112PE pulse




Example of a 123PE pulse




Example of a 133PE pulse




Example of a 96PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 89PE pulse




Example of a 91PE pulse




Example of a 123PE pulse




Example of a 101PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 71PE pulse




Example of a 81PE pulse




Example of a 121PE pulse




Example of a 111PE pulse




1023 PE distribution x=100mm y=25mm




1023 PE distribution x=100mm y=25mm




# 1023 PE distribution x=100mm y=25mm




Example of a 356PE pulse




Example of a 290PE pulse




Example of a 178PE pulse




Example of a 183PE pulse




1023 PE distribution x=100mm y=25mm




Example of a 165PE pulse




Example of a 101PE pulse



Example of a 98PE pulse




Example of a 126PE pulse







# 1023 PE distribution x=100mm y=25mm




Example of a 78PE pulse




Example of a 90PE pulse




Example of a 49PE pulse




Example of a 62PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 66PE pulse




Example of a 44PE pulse




Example of a 167PE pulse




Example of a 187PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 44PE pulse




Example of a 42PE pulse




Example of a 60PE pulse




Example of a 63PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 48PE pulse




Example of a 40PE pulse




Example of a 46PE pulse




Example of a 51PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 89PE pulse




Example of a 86PE pulse




Example of a 70PE pulse




Example of a 85PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 40PE pulse




Example of a 51PE pulse




Example of a 75PE pulse




Example of a 53PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 80PE pulse




Example of a 86PE pulse




Example of a 43PE pulse




Example of a 48PE pulse




# 1023 PE distribution x=100mm y=25mm




Example of a 82PE pulse



Example of a 56PE pulse



Example of a 43PE pulse



Example of a 48PE pulse

