




# 1331 PE distribution x=2250mm y=75mm




Example of a 54PE pulse




Example of a 81PE pulse




Example of a 98PE pulse




Example of a 282PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 110PE pulse




Example of a 117PE pulse




Example of a 57PE pulse




Example of a 54PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 30PE pulse




Example of a 37PE pulse




Example of a 206PE pulse




Example of a 258PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 102PE pulse




Example of a 98PE pulse




Example of a 40PE pulse




Example of a 29PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 40PE pulse




Example of a 56PE pulse




Example of a 197PE pulse




Example of a 209PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 38PE pulse




Example of a 48PE pulse




Example of a 31PE pulse




Example of a 40PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 45PE pulse




Example of a 50PE pulse




Example of a 167PE pulse




Example of a 191PE pulse




1331 PE distribution x=2250mm y=75mm




Example of a 23PE pulse




Example of a 58PE pulse



Example of a 27PE pulse




Example of a 40PE pulse







# 1331 PE distribution x=2250mm y=75mm




Example of a 97PE pulse




Example of a 48PE pulse




Example of a 126PE pulse




Example of a 124PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 158PE pulse




Example of a 152PE pulse




Example of a 78PE pulse




Example of a 59PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 33PE pulse




Example of a 67PE pulse




Example of a 63PE pulse




Example of a 301PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 158PE pulse




Example of a 123PE pulse




Example of a 63PE pulse




Example of a 39PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 57PE pulse




Example of a 45PE pulse




Example of a 288PE pulse




Example of a 269PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 67PE pulse




Example of a 60PE pulse




Example of a 66PE pulse




Example of a 48PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 162PE pulse




Example of a 125PE pulse




Example of a 47PE pulse




Example of a 131PE pulse




# 1331 PE distribution x=2250mm y=75mm




Example of a 48PE pulse



Example of a 32PE pulse



Example of a 41PE pulse



Example of a 46PE pulse

