




818 PE distribution x=2250mm y=75mm




Example of a 42PE pulse




Example of a 54PE pulse




Example of a 49PE pulse




Example of a 62PE pulse




818 PE distribution x=2250mm y=75mm




Example of a 60PE pulse




Example of a 54PE pulse




Example of a 72PE pulse




Example of a 69PE pulse




818 PE distribution x=2250mm y=75mm




Example of a 64PE pulse




Example of a 74PE pulse




Example of a 97PE pulse




Example of a 85PE pulse




818 PE distribution x=2250mm y=75mm




Example of a 114PE pulse




Example of a 115PE pulse




Example of a 59PE pulse




Example of a 74PE pulse




818 PE distribution x=2250mm y=75mm




Example of a 40PE pulse




Example of a 28PE pulse




Example of a 27PE pulse




Example of a 30PE pulse




818 PE distribution x=2250mm y=75mm




Example of a 37PE pulse




Example of a 56PE pulse




Example of a 47PE pulse




Example of a 33PE pulse




818 PE distribution x=2250mm y=75mm




Example of a 50PE pulse




Example of a 45PE pulse




Example of a 46PE pulse




Example of a 59PE pulse




818 PE distribution x=2250mm y=75mm




Example of a 89PE pulse



Example of a 80PE pulse



Example of a 58PE pulse



Example of a 64PE pulse

