




1294 PE distribution x=1500mm y=25mm




Example of a 70PE pulse




Example of a 65PE pulse




Example of a 94PE pulse




Example of a 82PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 106PE pulse




Example of a 126PE pulse




Example of a 110PE pulse




Example of a 142PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 74PE pulse




Example of a 100PE pulse




Example of a 83PE pulse




Example of a 27PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 64PE pulse




Example of a 71PE pulse




Example of a 88PE pulse




Example of a 109PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 71PE pulse




Example of a 74PE pulse




Example of a 72PE pulse




Example of a 51PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 63PE pulse




Example of a 58PE pulse




Example of a 65PE pulse




Example of a 77PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 60PE pulse




Example of a 64PE pulse




Example of a 66PE pulse




Example of a 77PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 141PE pulse




Example of a 126PE pulse




Example of a 42PE pulse




Example of a 69PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 94PE pulse




Example of a 63PE pulse




Example of a 94PE pulse




Example of a 75PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 120PE pulse




Example of a 131PE pulse




Example of a 105PE pulse




Example of a 153PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 91PE pulse




Example of a 66PE pulse




Example of a 29PE pulse




Example of a 26PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 59PE pulse




Example of a 75PE pulse




Example of a 103PE pulse




Example of a 103PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 71PE pulse




Example of a 67PE pulse




Example of a 71PE pulse




Example of a 65PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 56PE pulse




Example of a 54PE pulse




Example of a 58PE pulse




Example of a 89PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 57PE pulse




Example of a 64PE pulse




Example of a 60PE pulse




Example of a 66PE pulse




1294 PE distribution x=1500mm y=25mm




Example of a 150PE pulse



Example of a 136PE pulse



Example of a 62PE pulse



Example of a 75PE pulse

