




# 1273 PE distribution x=10mm y=25mm




Example of a 73PE pulse




Example of a 47PE pulse




Example of a 59PE pulse




Example of a 66PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 244PE pulse




Example of a 291PE pulse




Example of a 152PE pulse




Example of a 196PE pulse




# 1273 PE distribution x=10mm y=25mm




# 1273 PE distribution x=10mm y=25mm




1273 PE distribution x=10mm y=25mm




# 1273 PE distribution x=10mm y=25mm




# 1273 PE distribution x=10mm y=25mm




Example of a 149PE pulse




Example of a 119PE pulse




Example of a 84PE pulse




Example of a 77PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 208PE pulse




Example of a 171PE pulse



Example of a 23PE pulse




Example of a 28PE pulse







# 1273 PE distribution x=10mm y=25mm




Example of a 36PE pulse




Example of a 27PE pulse




Example of a 26PE pulse




Example of a 26PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 120PE pulse




Example of a 168PE pulse




Example of a 77PE pulse




Example of a 103PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 42PE pulse




Example of a 45PE pulse




Example of a 48PE pulse




Example of a 33PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 24PE pulse




Example of a 20PE pulse




Example of a 50PE pulse




Example of a 84PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 43PE pulse




Example of a 30PE pulse




Example of a 28PE pulse




Example of a 29PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 243PE pulse




Example of a 220PE pulse




Example of a 71PE pulse




Example of a 65PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 59PE pulse




Example of a 73PE pulse




Example of a 40PE pulse




Example of a 30PE pulse




# 1273 PE distribution x=10mm y=25mm




Example of a 70PE pulse



Example of a 134PE pulse



Example of a 114PE pulse



Example of a 20PE pulse

