




# 807 PE distribution x=1000mm y=25mm




Example of a 43PE pulse




Example of a 42PE pulse




Example of a 80PE pulse




Example of a 86PE pulse




# 807 PE distribution x=1000mm y=25mm




Example of a 86PE pulse




Example of a 82PE pulse




Example of a 124PE pulse




Example of a 115PE pulse




# 807 PE distribution x=1000mm y=25mm




Example of a 51PE pulse




Example of a 62PE pulse




Example of a 132PE pulse




Example of a 103PE pulse




# 807 PE distribution x=1000mm y=25mm




Example of a 59PE pulse




Example of a 57PE pulse




Example of a 176PE pulse




Example of a 179PE pulse




# 807 PE distribution x=1000mm y=25mm




Example of a 56PE pulse




Example of a 46PE pulse




Example of a 95PE pulse




Example of a 88PE pulse




# 807 PE distribution x=1000mm y=25mm




Example of a 116PE pulse




Example of a 129PE pulse




Example of a 160PE pulse




Example of a 163PE pulse




# 807 PE distribution x=1000mm y=25mm




Example of a 85PE pulse




Example of a 74PE pulse




Example of a 164PE pulse




Example of a 130PE pulse




# 807 PE distribution x=1000mm y=25mm




Example of a 63PE pulse



Example of a 52PE pulse



Example of a 238PE pulse



Example of a 192PE pulse

