




# 801 PE distribution x=300mm y=75mm




Example of a 28PE pulse




Example of a 35PE pulse




Example of a 53PE pulse




Example of a 44PE pulse




# 801 PE distribution x=300mm y=75mm




Example of a 51PE pulse




Example of a 34PE pulse




Example of a 36PE pulse




Example of a 36PE pulse




# 801 PE distribution x=300mm y=75mm




Example of a 48PE pulse




Example of a 58PE pulse




Example of a 47PE pulse




Example of a 50PE pulse




# 801 PE distribution x=300mm y=75mm




Example of a 45PE pulse




Example of a 46PE pulse




Example of a 59PE pulse




Example of a 54PE pulse




# 801 PE distribution x=300mm y=75mm




Example of a 56PE pulse




Example of a 45PE pulse




Example of a 60PE pulse




Example of a 65PE pulse




# 801 PE distribution x=300mm y=75mm




Example of a 77PE pulse




Example of a 72PE pulse




Example of a 70PE pulse




Example of a 50PE pulse




# 801 PE distribution x=300mm y=75mm




Example of a 75PE pulse




Example of a 89PE pulse




Example of a 77PE pulse




Example of a 88PE pulse




# 801 PE distribution x=300mm y=75mm




Example of a 69PE pulse



Example of a 73PE pulse



Example of a 100PE pulse



Example of a 93PE pulse

