




# 1268 PE distribution x=150mm y=25mm




Example of a 112PE pulse




Example of a 133PE pulse




Example of a 130PE pulse




Example of a 142PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 112PE pulse




Example of a 114PE pulse




Example of a 309PE pulse




Example of a 299PE pulse




1268 PE distribution x=150mm y=25mm




1268 PE distribution x=150mm y=25mm




1268 PE distribution x=150mm y=25mm




1268 PE distribution x=150mm y=25mm




# 1268 PE distribution x=150mm y=25mm




Example of a 111PE pulse




Example of a 107PE pulse




Example of a 80PE pulse




Example of a 85PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 324PE pulse




Example of a 327PE pulse



Example of a 258PE pulse




Example of a 297PE pulse







# 1268 PE distribution x=150mm y=25mm




Example of a 46PE pulse




Example of a 62PE pulse




Example of a 76PE pulse




Example of a 79PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 52PE pulse




Example of a 47PE pulse




Example of a 205PE pulse




Example of a 186PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 59PE pulse




Example of a 45PE pulse




Example of a 42PE pulse




Example of a 42PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 71PE pulse




Example of a 78PE pulse




Example of a 138PE pulse




Example of a 180PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 121PE pulse




Example of a 122PE pulse




Example of a 69PE pulse




Example of a 110PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 84PE pulse




Example of a 89PE pulse




Example of a 38PE pulse




Example of a 39PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 88PE pulse




Example of a 54PE pulse




Example of a 36PE pulse




Example of a 50PE pulse




# 1268 PE distribution x=150mm y=25mm




Example of a 227PE pulse



Example of a 246PE pulse



Example of a 181PE pulse



Example of a 217PE pulse

