




# 1280 PE distribution x=50mm y=75mm




Example of a 267PE pulse




Example of a 277PE pulse




Example of a 143PE pulse




Example of a 134PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 107PE pulse




Example of a 94PE pulse




Example of a 117PE pulse




Example of a 108PE pulse





# 1280 PE distribution x=50mm y=75mm




# 1280 PE distribution x=50mm y=75mm




# 1280 PE distribution x=50mm y=75mm




# 1280 PE distribution x=50mm y=75mm




# 1280 PE distribution x=50mm y=75mm




Example of a 99PE pulse




Example of a 75PE pulse




Example of a 97PE pulse




Example of a 82PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 100PE pulse




Example of a 101PE pulse



Example of a 80PE pulse




Example of a 100PE pulse







# 1280 PE distribution x=50mm y=75mm




Example of a 147PE pulse




Example of a 132PE pulse




Example of a 82PE pulse




Example of a 73PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 57PE pulse




Example of a 31PE pulse




Example of a 61PE pulse




Example of a 52PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 75PE pulse




Example of a 86PE pulse




Example of a 63PE pulse




Example of a 49PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 44PE pulse




Example of a 40PE pulse




Example of a 27PE pulse




Example of a 32PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 52PE pulse




Example of a 63PE pulse




Example of a 270PE pulse




Example of a 301PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 60PE pulse




Example of a 32PE pulse




Example of a 48PE pulse




Example of a 42PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 36PE pulse




Example of a 50PE pulse




Example of a 249PE pulse




Example of a 273PE pulse




# 1280 PE distribution x=50mm y=75mm




Example of a 45PE pulse



Example of a 46PE pulse



Example of a 38PE pulse



Example of a 44PE pulse

