




1145 PE distribution x=1000mm y=75mm




Example of a 118PE pulse




Example of a 125PE pulse




Example of a 114PE pulse




Example of a 90PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 20PE pulse




Example of a 21PE pulse




Example of a 21PE pulse




Example of a 21PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 181PE pulse




Example of a 27PE pulse




Example of a 120PE pulse




Example of a 149PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 21PE pulse




Example of a 25PE pulse




Example of a 24PE pulse




Example of a 20PE pulse




1145 PE distribution x=1000mm y=75mm




1145 PE distribution x=1000mm y=75mm




1145 PE distribution x=1000mm y=75mm




1145 PE distribution x=1000mm y=75mm




Example of a 20PE pulse




Example of a 20PE pulse




Example of a 60PE pulse




Example of a 88PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 123PE pulse




Example of a 110PE pulse




Example of a 21PE pulse




Example of a 33PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 20PE pulse




Example of a 24PE pulse




Example of a 24PE pulse




Example of a 25PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 126PE pulse




Example of a 225PE pulse




Example of a 64PE pulse




Example of a 97PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 34PE pulse




Example of a 22PE pulse




Example of a 20PE pulse




Example of a 23PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 88PE pulse




Example of a 107PE pulse




Example of a 106PE pulse




Example of a 26PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 86PE pulse




Example of a 73PE pulse




Example of a 67PE pulse




Example of a 21PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 71PE pulse




Example of a 152PE pulse




Example of a 120PE pulse




Example of a 159PE pulse




1145 PE distribution x=1000mm y=75mm




Example of a 28PE pulse



Example of a 113PE pulse



Example of a 94PE pulse



Example of a 23PE pulse

