




# 802 PE distribution x=500mm y=75mm




Example of a 52PE pulse




Example of a 46PE pulse




Example of a 57PE pulse




Example of a 53PE pulse




# 802 PE distribution x=500mm y=75mm




Example of a 42PE pulse




Example of a 59PE pulse




Example of a 102PE pulse




Example of a 99PE pulse




# 802 PE distribution x=500mm y=75mm




Example of a 45PE pulse




Example of a 50PE pulse




Example of a 62PE pulse




Example of a 69PE pulse




# 802 PE distribution x=500mm y=75mm




Example of a 56PE pulse




Example of a 68PE pulse




Example of a 53PE pulse




Example of a 51PE pulse




# 802 PE distribution x=500mm y=75mm




Example of a 68PE pulse




Example of a 74PE pulse




Example of a 103PE pulse




Example of a 85PE pulse




# 802 PE distribution x=500mm y=75mm




Example of a 67PE pulse




Example of a 82PE pulse




Example of a 124PE pulse




Example of a 157PE pulse




# 802 PE distribution x=500mm y=75mm




Example of a 75PE pulse




Example of a 68PE pulse




Example of a 99PE pulse




Example of a 95PE pulse




# 802 PE distribution x=500mm y=75mm




Example of a 88PE pulse



Example of a 86PE pulse



Example of a 74PE pulse



Example of a 72PE pulse

