




1150 PE distribution x=1000mm y=75mm




Example of a 52PE pulse




Example of a 47PE pulse




Example of a 79PE pulse




Example of a 65PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 93PE pulse




Example of a 71PE pulse




Example of a 59PE pulse




Example of a 50PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 69PE pulse




Example of a 62PE pulse




Example of a 60PE pulse




Example of a 66PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 76PE pulse




Example of a 73PE pulse




Example of a 62PE pulse




Example of a 44PE pulse




1150 PE distribution x=1000mm y=75mm




1150 PE distribution x=1000mm y=75mm




1150 PE distribution x=1000mm y=75mm




Example of a 54PE pulse




Example of a 33PE pulse




Example of a 47PE pulse




Example of a 48PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 67PE pulse




Example of a 60PE pulse




Example of a 79PE pulse




Example of a 73PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 68PE pulse




Example of a 106PE pulse




Example of a 63PE pulse




Example of a 71PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 85PE pulse




Example of a 74PE pulse




Example of a 86PE pulse




Example of a 99PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 29PE pulse




Example of a 132PE pulse




Example of a 56PE pulse




Example of a 156PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 86PE pulse




Example of a 69PE pulse




Example of a 52PE pulse




Example of a 42PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 60PE pulse




Example of a 65PE pulse




Example of a 77PE pulse




Example of a 46PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 88PE pulse




Example of a 74PE pulse




Example of a 46PE pulse




Example of a 41PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 40PE pulse




Example of a 39PE pulse




Example of a 36PE pulse




Example of a 46PE pulse




1150 PE distribution x=1000mm y=75mm




Example of a 63PE pulse



Example of a 51PE pulse



Example of a 60PE pulse



Example of a 56PE pulse

