




1278 PE distribution x=10mm y=75mm




Example of a 201PE pulse




Example of a 174PE pulse




Example of a 102PE pulse




Example of a 126PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 162PE pulse




Example of a 78PE pulse




Example of a 78PE pulse




Example of a 73PE pulse




1278 PE distribution x=10mm y=75mm




1278 PE distribution x=10mm y=75mm




1278 PE distribution x=10mm y=75mm




1278 PE distribution x=10mm y=75mm




1278 PE distribution x=10mm y=75mm




Example of a 320PE pulse




Example of a 287PE pulse




Example of a 89PE pulse




Example of a 86PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 137PE pulse




Example of a 111PE pulse




Example of a 103PE pulse




Example of a 61PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 333PE pulse




Example of a 305PE pulse




Example of a 58PE pulse




Example of a 62PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 50PE pulse




Example of a 48PE pulse




Example of a 27PE pulse




Example of a 26PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 32PE pulse




Example of a 28PE pulse




Example of a 26PE pulse




Example of a 24PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 22PE pulse




Example of a 21PE pulse




Example of a 22PE pulse




Example of a 26PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 60PE pulse




Example of a 63PE pulse




Example of a 227PE pulse




Example of a 267PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 43PE pulse




Example of a 34PE pulse




Example of a 43PE pulse




Example of a 32PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 226PE pulse




Example of a 198PE pulse




Example of a 35PE pulse




Example of a 33PE pulse




1278 PE distribution x=10mm y=75mm




Example of a 73PE pulse



Example of a 67PE pulse



Example of a 45PE pulse



Example of a 41PE pulse

