




796 PE distribution x=100mm y=25mm




Example of a 38PE pulse




Example of a 39PE pulse




Example of a 32PE pulse




Example of a 31PE pulse




796 PE distribution x=100mm y=25mm




Example of a 42PE pulse




Example of a 38PE pulse




Example of a 38PE pulse




Example of a 38PE pulse




796 PE distribution x=100mm y=25mm




Example of a 32PE pulse




Example of a 47PE pulse




Example of a 22PE pulse




Example of a 36PE pulse




796 PE distribution x=100mm y=25mm




Example of a 37PE pulse




Example of a 32PE pulse




Example of a 26PE pulse




Example of a 59PE pulse




796 PE distribution x=100mm y=25mm




Example of a 76PE pulse




Example of a 71PE pulse




Example of a 76PE pulse




Example of a 57PE pulse




796 PE distribution x=100mm y=25mm




Example of a 86PE pulse




Example of a 63PE pulse




Example of a 68PE pulse




Example of a 82PE pulse




796 PE distribution x=100mm y=25mm




Example of a 79PE pulse




Example of a 77PE pulse




Example of a 67PE pulse




Example of a 86PE pulse




796 PE distribution x=100mm y=25mm




Example of a 81PE pulse



Example of a 67PE pulse



Example of a 59PE pulse



Example of a 78PE pulse

