




# 812 PE distribution x=1500mm y=25mm




Example of a 71PE pulse




Example of a 90PE pulse




Example of a 80PE pulse




Example of a 91PE pulse




# 812 PE distribution x=1500mm y=25mm




Example of a 87PE pulse




Example of a 85PE pulse




Example of a 52PE pulse




Example of a 74PE pulse




# 812 PE distribution x=1500mm y=25mm




Example of a 62PE pulse




Example of a 85PE pulse




Example of a 75PE pulse




Example of a 89PE pulse




# 812 PE distribution x=1500mm y=25mm




Example of a 50PE pulse




Example of a 67PE pulse




Example of a 53PE pulse




Example of a 57PE pulse




# 812 PE distribution x=1500mm y=25mm




Example of a 68PE pulse




Example of a 80PE pulse




Example of a 108PE pulse




Example of a 112PE pulse




# 812 PE distribution x=1500mm y=25mm




Example of a 88PE pulse




Example of a 84PE pulse




Example of a 65PE pulse




Example of a 69PE pulse




# 812 PE distribution x=1500mm y=25mm




Example of a 81PE pulse




Example of a 75PE pulse




Example of a 50PE pulse




Example of a 60PE pulse




# 812 PE distribution x=1500mm y=25mm




Example of a 51PE pulse



Example of a 66PE pulse



Example of a 49PE pulse



Example of a 65PE pulse

