




800 PE distribution x=300mm y=25mm




Example of a 24PE pulse




Example of a 37PE pulse




Example of a 28PE pulse




Example of a 41PE pulse




800 PE distribution x=300mm y=25mm




Example of a 49PE pulse




Example of a 42PE pulse




Example of a 42PE pulse




Example of a 38PE pulse




800 PE distribution x=300mm y=25mm




Example of a 37PE pulse




Example of a 38PE pulse




Example of a 69PE pulse




Example of a 76PE pulse




800 PE distribution x=300mm y=25mm




Example of a 45PE pulse




Example of a 46PE pulse




Example of a 72PE pulse




Example of a 59PE pulse




800 PE distribution x=300mm y=25mm




Example of a 71PE pulse




Example of a 68PE pulse




Example of a 56PE pulse




Example of a 67PE pulse




800 PE distribution x=300mm y=25mm




Example of a 68PE pulse




Example of a 78PE pulse




Example of a 74PE pulse




Example of a 69PE pulse




800 PE distribution x=300mm y=25mm




Example of a 78PE pulse




Example of a 71PE pulse




Example of a 110PE pulse




Example of a 98PE pulse




800 PE distribution x=300mm y=25mm




Example of a 63PE pulse



Example of a 88PE pulse



Example of a 85PE pulse



Example of a 105PE pulse

