




# 1287 PE distribution x=500mm y=75mm




Example of a 304PE pulse




Example of a 281PE pulse




Example of a 46PE pulse




Example of a 41PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 94PE pulse




Example of a 106PE pulse




Example of a 80PE pulse




Example of a 75PE pulse





1287 PE distribution x=500mm y=75mm




1287 PE distribution x=500mm y=75mm




# 1287 PE distribution x=500mm y=75mm




1287 PE distribution x=500mm y=75mm




# 1287 PE distribution x=500mm y=75mm




Example of a 349PE pulse




Example of a 306PE pulse




Example of a 271PE pulse




Example of a 245PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 111PE pulse




Example of a 94PE pulse



Example of a 67PE pulse




Example of a 69PE pulse







# 1287 PE distribution x=500mm y=75mm




Example of a 38PE pulse




Example of a 212PE pulse




Example of a 180PE pulse




Example of a 29PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 76PE pulse




Example of a 65PE pulse




Example of a 63PE pulse




Example of a 39PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 135PE pulse




Example of a 120PE pulse




Example of a 41PE pulse




Example of a 37PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 93PE pulse




Example of a 86PE pulse




Example of a 46PE pulse




Example of a 31PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 107PE pulse




Example of a 108PE pulse




Example of a 215PE pulse




Example of a 227PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 88PE pulse




Example of a 81PE pulse




Example of a 87PE pulse




Example of a 61PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 257PE pulse




Example of a 248PE pulse




Example of a 177PE pulse




Example of a 161PE pulse




# 1287 PE distribution x=500mm y=75mm




Example of a 91PE pulse



Example of a 60PE pulse



Example of a 52PE pulse



Example of a 51PE pulse

