




842 PE distribution x=100mm y=25mm




Example of a 29PE pulse




Example of a 27PE pulse




Example of a 32PE pulse




Example of a 29PE pulse




842 PE distribution x=100mm y=25mm




Example of a 57PE pulse




Example of a 64PE pulse




Example of a 41PE pulse




Example of a 25PE pulse




842 PE distribution x=100mm y=25mm




Example of a 85PE pulse




Example of a 72PE pulse




Example of a 36PE pulse




Example of a 27PE pulse




842 PE distribution x=100mm y=25mm




Example of a 70PE pulse




Example of a 76PE pulse




Example of a 45PE pulse




Example of a 40PE pulse




842 PE distribution x=100mm y=25mm




Example of a 62PE pulse




Example of a 66PE pulse




Example of a 70PE pulse




Example of a 50PE pulse




842 PE distribution x=100mm y=25mm




Example of a 123PE pulse




Example of a 118PE pulse




Example of a 79PE pulse




Example of a 88PE pulse




842 PE distribution x=100mm y=25mm




Example of a 166PE pulse




Example of a 162PE pulse




Example of a 96PE pulse




Example of a 64PE pulse




842 PE distribution x=100mm y=25mm




Example of a 154PE pulse



Example of a 148PE pulse



Example of a 84PE pulse



Example of a 81PE pulse

