




# 1285 PE distribution x=250mm y=75mm




Example of a 184PE pulse




Example of a 148PE pulse




Example of a 99PE pulse




Example of a 114PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 210PE pulse




Example of a 184PE pulse




Example of a 153PE pulse




Example of a 126PE pulse




1285 PE distribution x=250mm y=75mm




1285 PE distribution x=250mm y=75mm




1285 PE distribution x=250mm y=75mm




1285 PE distribution x=250mm y=75mm




# 1285 PE distribution x=250mm y=75mm




Example of a 91PE pulse




Example of a 78PE pulse




Example of a 91PE pulse




Example of a 107PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 215PE pulse




Example of a 164PE pulse



Example of a 131PE pulse




Example of a 135PE pulse







# 1285 PE distribution x=250mm y=75mm




Example of a 106PE pulse




Example of a 86PE pulse




Example of a 124PE pulse




Example of a 141PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 113PE pulse




Example of a 94PE pulse




Example of a 84PE pulse




Example of a 66PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 30PE pulse




Example of a 45PE pulse




Example of a 103PE pulse




Example of a 102PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 145PE pulse




Example of a 137PE pulse




Example of a 45PE pulse




Example of a 60PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 79PE pulse




Example of a 101PE pulse




Example of a 160PE pulse




Example of a 217PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 245PE pulse




Example of a 238PE pulse




Example of a 82PE pulse




Example of a 75PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 46PE pulse




Example of a 47PE pulse




Example of a 120PE pulse




Example of a 134PE pulse




# 1285 PE distribution x=250mm y=75mm




Example of a 115PE pulse



Example of a 119PE pulse



Example of a 74PE pulse



Example of a 69PE pulse

