




835 PE distribution x=500mm y=25mm




Example of a 45PE pulse




Example of a 56PE pulse




Example of a 39PE pulse




Example of a 39PE pulse




835 PE distribution x=500mm y=25mm




Example of a 55PE pulse




Example of a 43PE pulse




Example of a 37PE pulse




Example of a 42PE pulse




835 PE distribution x=500mm y=25mm




Example of a 45PE pulse




Example of a 41PE pulse




Example of a 53PE pulse




Example of a 53PE pulse




835 PE distribution x=500mm y=25mm




Example of a 68PE pulse




Example of a 70PE pulse




Example of a 47PE pulse




Example of a 55PE pulse




835 PE distribution x=500mm y=25mm




Example of a 84PE pulse




Example of a 117PE pulse




Example of a 60PE pulse




Example of a 48PE pulse




835 PE distribution x=500mm y=25mm




Example of a 78PE pulse




Example of a 77PE pulse




Example of a 80PE pulse




Example of a 88PE pulse




835 PE distribution x=500mm y=25mm




Example of a 77PE pulse




Example of a 95PE pulse




Example of a 73PE pulse




Example of a 90PE pulse




835 PE distribution x=500mm y=25mm




Example of a 111PE pulse



Example of a 107PE pulse



Example of a 90PE pulse



Example of a 104PE pulse

